
Pointwise Operations and Gamma

Histogram of an Image


Input Image kids.tif





Input Image race.tif





Histogram Equalization for kids.tif


```
def equalize(x: np.array, path: str):
    hist, bins = np.histogram(x.flatten(), bins=np.linspace(0, 255, 256))
    cdf = hist.cumsum()
    cdf_normalized = cdf * float(hist.max()) / cdf.max()
    equalized_hist = np.interp(x, bins[:-1], cdf_normalized)


# Plot the normalized CDF
    plt.plot(cdf_normalized)
    plt.title('Normalized CDF')
```


```
plt.xlabel('Pixel Intensity')
plt.ylabel('CDF')
plt.savefig(Path(path).stem + '_normalized_cdf.png')
plt.close()

# Plot the equalized histogram
plt.hist(equalized_hist.flatten(), bins=256)
plt.title('Equalized Histogram')
plt.xlabel('Pixel Intensity')
plt.ylabel('Frequency')
plt.savefig(Path(path).stem + '_equalized_hist.png')
plt.close()

plt.imsave(Path(path).stem + '_equalized.png', x, cmap='gray')
```









Contrast Stretching of kids.tif

```
def stretch(input_image, T1, T2, path: str):
    # Ensure input image is of type uint8
    input_image = np.asarray(input_image, dtype=np.uint8)

# Create an output array of the same shape as the input image output_image = np.zeros_like(input_image)


# Apply the contrast stretching transformation output_image[input_image <= T1] = 0</pre>
```

```
output_image[input_image >= T2] = 255
output_image[(input_image > T1) & (input_image < T2)] = ((input_image[(input_image]))
# Plot the equalized histogram
plt.hist(output_image.flatten(), bins=np.linspace(0, 255, 256))
plt.title('Stretched Histogram')
plt.xlabel('Pixel Intensity')
plt.ylabel('Frequency')
plt.savefig(Path(path).stem + '_stretch_hist.png')
plt.close()

plt.imsave(Path(path).stem + '_stretch.png', output_image, cmap='gray')</pre>
```




Stretched Histogram



Gamma

Monitor Gamma

Matching Gray Level = 170



Derivation Relating Gray Level to Gamma

The perceived intensity of the checkerboard (I_c) , is given by:

$$I_c=(rac{I_{255}+0}{2})$$

The percieved intensity of the gray level g (I_g), produced by the monitor is given by:

$$I_g = I_{255}(rac{g}{255})^{\gamma}$$

To find the value of γ for the monitor, we need to determine the gray level g which makes $I_g = I_c$.

Substituting, we have:

$$rac{I_{255}+0}{2}=I_{255}(rac{g}{255})^{\gamma}$$

Solving for γ creates a relation directly to g, gray level.

$$\left(\frac{g}{255}\right)^{\gamma} = \frac{1}{2}$$

$$\gamma = rac{\log(rac{1}{2})}{\log(rac{g}{255})}$$

Measured Gray Level and Gamma

Monitor Gamma = 1.7

Measured Gray Level = 170

Gamma Correction

Original linear.tif



Corrected linear.tif



Original gamma15.tif



Corrected gamma15.tif to Monitor Gamma (1.7)

Performed correction from $\gamma=1.5$ to $\gamma=1.7$ by:

- 1. Converting the image to linear scaling using the gamma of the image and the standard equation
- 2. Converting this linear image back to a gamma corrected version using the monitor's gamma and the inverse equation

